RoughDeck® Access Ramps



RoughDeck Access Ramps

Part #	Size (W x L x H)	Est. Weight	Price	
RoughDecl	RoughDeck HP: 1,000–10,000 lb (diamond treadplate standard)			
69040*	2.5ft x 3ft x 3.5in	115lb	Consult	
69041*	3ft x 3ft x 3.5in	133 lb	Consult	
69042*	4ft x 3ft x 3.5 in	177 lb	Consult	
69043*	5ft x 3ft x 3.5in	226 lb	Consult	
69184	2.5ft x 4ft x 3.5in	152 lb	Consult	
69185	3ft x 4ft x 3.5 in	177 lb	Consult	
69186	4ft x 4ft x 3.5in	224 lb	Consult	
69187	5ft x 4ft x 3.5 in	272 lb	Consult	
RoughDec	(HP-H: 20,000 lb (diamond treadplate standard)			
69204	4ft x 4ft x 4in	487 lb	Consult	
69205	5ft x 4ft x 4in	591 lb	Consult	
69206	6 ft x 4 ft x 4 in	689 lb	Consult	
69207	7 ft x 4 ft x 4 in	822 lb	Consult	
69208	8ft x 4ft x 4in	1005 lb	Consult	
RoughDeck HP-H: 30,000 lb (diamond treadplate standard)				
69210	4ft x 5ft x 5in	666 lb	Consult	
69211	5ft x 5ft x 5 in	806 lb	Consult	
69212	6ft x 5ft x 5in	942 lb	Consult	
69213	7 ft x 5 ft x 5 in	1116lb	Consult	
69214	8 ft x 5 ft x 5 in	1337 lb	Consult	
	s SS and HE: 1,000–10,000 lb (diamond treadplate standard)			
69178*	2.5ft x 3ft x 3.5in	115lb	Consult	
69179*	3ft x 3ft x 3.5 in	133 lb	Consult	
69180*	4ft x 3ft x 3.5 in	177 lb	Consult	
69189	2.5ft x 4ft x 3.5 in	152 lb	Consult	
69190	3ft x 4ft x 3.5 in	177 lb	Consult	
69191	4ft x 4ft x 3.5 in	224 lb	Consult	
69192	5ft x 4ft x 3.5in	272 lb	Consult	

* Not recommended for use with pallet jacks

NOTE: Approach length must match width of ramp with width of scale

NOTE: Part numbered ramps are designed to fit scale on sides perpendicular to junction box. The junction box is always on longest side of scale unless specified differently.


NOTE: Part numbered ramps are designed to fit scale sides A or C, if you need a ramp to fit scale side B or D please request a quote for a special ramp

Options/Accessories

Part #	Description	Price
NI/A	Epoya paint	+Consult list
N/A	Epoxy paint	price add-on

432

RoughDeck® Access Ramps



Part numbered ramps are designed to fit scale sides A or C, if you need a ramp to fit scale side B or D please request a quote for a special ramp. The junction box is always on the longest side of the scale unless specified differently.